



SCAT MACHINE

OPERATING INSTRUCTIONS


- If SCAT machine door is CLOSED, PRESS BLUE ACTIVATE button and wait for an audible CLICK before opening.
- If SCAT machine door is OPEN, PROCEED with further instructions.



Eco-Safe with 20mm Ammo Can




20MM Ammo Can




Johnny Partner



5-Gallon Bucket



Selway River Bank II



Coyote

1. Place toilet right side up on hopper door as shown in examples.
2. Be sure toilet is centered and positioned against the back of hopper door.
3. Securely strap toilet to hopper door using the back and bottom anchor points.
 - Make sure straps are tight in all directions!
4. Be sure buckles and strap ends are tied short, so they don't interfere with cleaning mechanism or door.
5. Remove toilet seat and lid.
6. Place toilet seat and lid in accessory rack at the back of hopper.
 - Make sure soiled surface faces to back of the hopper.
 - Do not overlap or stack accessories.
7. Gently close the hopper door — DO NOT SLAM!!
 - Your toilet will empty it's contents into the machine as it positions over the cleaning wand to be sanitized.
8. Press GREEN START button and wait for wash cycle to complete.
9. Open the hopper door and remove toilet and accessories.
 - If your toilet needs a second wash, leave it strapped in and close the hopper door to start second wash cycle.

Tube-style toilet instructions and machine on other wall.